





Parts Identification Guide
PIC020/0405

Access Receiver





Access Receiver

- 1. Loader Lid
- 2. Filter
- 3. Loader Body
- 4. Loader Clamps (2 required)
- 5. Line Adapter
- 6. Seal / Liner
- 7. Air Cylinder
- 8. Common Line Valve
- 9. Lid - Common Line Valve
- 10. Clamp - Common Line Valve